

TIMBERSTICK AF

TimberStick AF

TimberStick AF is an acrylic polymer adhesive designed for use with engineered and parquet wood flooring and can be used to install most underlayments designed to be used under wood flooring. This adhesive can be used to install cork underlayment, but cannot be used to install cork finished flooring. With its easy to trowel application and exceptional green grab, it changes the way wood flooring is installed. Its green grab helps reduce any board slippage during installation. TimberStick AF holds its trowel ridge better than any other product on the market, this minimizes hollow spots and reduces call backs.





TimberStick AF Installation Instructions

- > TimberStick AF is an acrylic adhesive that contains water
- Once the adhesive is troweled the adhesive must be allowed to flash off for 10-15 minutes to release moisture in the adhesive
- > Non-Porous substrates require longer flash times
 - > Steel troweled concrete
 - > Cork underlayment
 - > Sheet vinyl
- > If TimberStick AF isn't allowed to flash off, the moisture being released from the adhesive could cause cupping in the wood flooring. (this cupping is temporary and will go away after 7-10 days).
- > TimberStick AF **DOES NOT** provide a moisture barrier. You must use Divergent PBR if the moisture levels are above manufacturers guidelines.

